

## BB 10 m repairs

### 1. Windows.

Windows and rabbet must be grounded with sand paper no. 150. The window is fitted on the rabbet such that you can mark how much area has to be grounded on the window. The window must be primed on the grounded area and let to dry for about 15 min. Silicone mass with a thickness of about 5 mm (0.2") should be put on the grounded and primed area quickly in order for the silicone not to harden in its surface. Bended nails secured with tape on the inside are used to hold the window in place. Should sit for at least 24 hours and holes, etc. can then be filled.

### 2. Polishing of the deck.

The deck must be cleaned thoroughly and can then be polished with lamb fur on a polisher using maximum 2000 rotations. Use Slippol auto polishing and kerosene as moistening.

### 3. Exchange of power cord in mast.

Tighten all ropes (halyards) such that by moving them one by one, you can see which of them makes the power cord move. An eye strap fitting at the spinnaker pole mast fitting and one at the foresail cutout must be removed (rivet drilled out) and caught with tape such that they do not fall down (if they fall down they have to be shaken all the way out of the bottom of the mast). Riveter should be removed with a drill (4.8 (0.19") or 5 mm (0.2")). The power cord is attached to a rope at the top and can then easily be exchanged.

