

## **Exchange of gas container in 12-tackle kick (boom vang)**

The gas container in HRS stainless steel kick losses its power after some years and must be replaced. The gas container is a standard component which is used e.g. to hold the back door or trunk door in vehicles. The following gas container from A/S H. Sindby, Vejle, fits the kick:

**B0N0-50-150-360—001 750N**

Before the kick is taken apart the rope must be removed from the sheaves. Then the needle (can be found under one set of sheaves) in the one end is removed. The kick has to be pulled to its maximum length and the inner tube should be fixed e.g. with a tool. The end opposite to where the needle was can now be unscrewed. If you are lucky the old gas container follows the end fitting but otherwise the old gas container has to be pulled or screwed out of the inner tube. **REMEMBER** to unscrew the extension tube on the piston of the gas container before it is thrown out, it has to be mounted on the new gas container! Assemble the kick with the new gas container in the opposite order.